

## **Requirement for Total Phosphorus and COD Sampling**

Please leave a small amount of air in your vials for TP, TDP and COD so they can be homogenized before analysis and the acid matrix is correct. These test are not volatiles, therefore don't get filled without air space.

Fill to the bend in the neck of vial as marked by the label.

Thank You!

